



# Fearful of Corrosion?

Then Check Out These  
Preventative Tips!

## Why use Better Engineering's Detergent?

The G-2000 & G-3000 parts washers are backed by a Lifetime warranty for the infrastructure elements of our turntable units. However, if corrosion happens due to not using the correct detergent warranty is voided.

\* See owner's manual

## What Type of Detergent Should You Use?

BetterEngineering's  
539-PDN-50-7310

## What is 539-PDN-50-7310?

A powdered detergent with rust inhibitor. A multi-metal safe, low temperature, heavy duty detergent. Its low foaming action is designed to remove heavy & light oils, greases, light carbon deposits and other contaminants.

## Best Practices for 539-PDN-50-7310 with BE Automatic Parts Washers

- Water must be heated up to 125-130°F (to prevent foaming)
- Apply powdered detergent onto the turntable then run a cycle
- Run the machine for several hours to coat the inside with the rust inhibitor
- Keep the door open at night to allow steam to escape to avoid corrosion
- Keep detergent concentration consistent to prevent rusting